

動作確認済み「デジタルカメラ一覧表」

<b>AipTek製</b>
AipTek PocketDV 3500
AipTek PocketCam 4000
<b>BenQ製</b>
BenQ DC140
BenQ DC2300
BenQ DC2310
BenQ DC2410
BenQ DC5330
BenQ DCC40
<b>キャノン製</b>
CANON 300D
CANON A300
CANON A60
CANON A75
CANON A80
CANON G5
CANON IXUS 1IS
CANON IXUS 400
CANON IXUS 500
CANON IXUS I
CANON PowerShotA60
CANON PowerShotA70
CANON PowerShotS50
CANON S1IS
CANON S50
CANON S60
CASIO EX-Z40
<b>***</b>
DIGILIFE DGL660
<b>エプソン製</b>
EPSON L-40
<b>FUJIFILM製</b>
FUJIFILM 3800
FUJIFILM A210
FUJIFILM A310
FUJIFILM A340
FUJIFILM F410
FUJIFILM F420
FUJIFILM F610
FUJIFILM F700
FUJIFILM FinePix F410
FUJIFILM FinePix2650
FUJIFILM Q1
FUJIFILM S20 PRO
FUJIFILM S5000
FUJIFILM S7000

<b>コダック製</b>
KODAK 7630
KODAK DX6490
KODAK DX6490
KODAK EasyShare DX340 USB2.0
KODAK EasyShare DX340 USB2.0
KODAK LS6-33
KODAK LS743
<b>コニカ製</b>
Konica KD-310Z
Konica KD-400Z
Konica KD-410Z
Konica KD-500Z
<b>京セラ製</b>
Kyocera Finecam S3L
Kyocera Finecam S5R
Kyocera Finecam SL300R
<b>ミノルタ製</b>
MINOLTA DiIMAGE 5
MINOLTA DiIMAGE 7Hi
MINOLTA DiIMAGE A1
MINOLTA DiIMAGE A2
MINOLTA DiIMAGE F200
MINOLTA DiIMAGE F300
MINOLTA DiIMAGE X20
MINOLTA DiIMAGE Xi
MINOLTA DiIMAGE Xt USB1.1
MINOLTA DiIMAGE Z1
MINOLTA DiIMAGE Z2
<b>MUSTEK製</b>
mustek dv4000
Mustek DV5500
Mustek mini DV
<b>ニコン製</b>
NIKON 3200
NIKON 4100
NIKON 5700
NIKON CoolPix 3100
NIKON CoolPix 4100
NIKON CoolPix 4200
NIKON CoolPix 4300
NIKON CoolPix 4500
NIKON CoolPix 5000
NIKON CoolPix 5700
NIKON CoolPix 8700
NIKON CoolPix D70
NIKON CoolPix SQ
NIKON D100
NIKON D70

<b>オリンパス製</b>
OLYMPUS C-150Z
OLYMPUS C-160Z
OLYMPUS C-2
OLYMPUS C-2Z
OLYMPUS C-310Z
OLYMPUS C-360Z
OLYMPUS C-4000Z
OLYMPUS C-460Z
OLYMPUS C-5000Z
OLYMPUS C-5050Z
OLYMPUS C-5060WZ
OLYMPUS C-5060Z
OLYMPUS C-50Z
OLYMPUS C-730
OLYMPUS C-730 WZ
OLYMPUS C-740 WZ
OLYMPUS C-750 WZ
OLYMPUS C-760 WZ
OLYMPUS C-765 WZ
OLYMPUS C-770WZ
OLYMPUS C-8080WZ
OLYMPUS Digital E-1
OLYMPUS MJU-300
OLYMPUS MJU-400
OLYMPUS MJU-410
OLYMPUS U100
OLYMPUS U200
OLYMPUS U300
OLYMPUS X-1
OLYMPUS X-2
<b>***</b>
ORIT EVC3240
<b>パナソニック製</b>
PANASONIC DV PV-GS50S
PANASONIC DMC-FX1
PANASONIC NV65
PANASONIC Z1
<b>***</b>
PANTAX S-40
<b>SamSung製</b>
SamSung Digimax 202
SamSung Digimax V3 USB1.1
Samsung Digimax V5
Samsung Digimax XT
Samsung Minolta
<b>サンヨー製</b>
Sanyo AZ1
Sanyo AZ3

<b>ソニー製</b>
SONY DV DCR-TRV22
Sony CyberShotUSB1.1
SONY DCR-TRV38E
SONY F717
SONY F77
SONY F828
SONY F828
SONY P1
SONY P100
SONY P12
SONY P32
SONY P43
SONY P52
SONY P72
SONY P73
SONY P77 USB1.1
SONY P8
SONY P9
SONY P92
SONY P93
SONY T1
SONY T11
SONY U20
SONY U30
SONY U50
SONY U60
SONY V1
SONY W1
<b>UMAX製</b>
UMAX AstraPix 610